

# Pro-Kit Bright Silver Detarnisher

## Description:

Bright Silver Detarnisher is a powder form cleanser which can effectively remove dried on food of cutlery or tarnish of silver ware with the aid of aluminum foil.

## 產品說明：

Bright 浸銀粉的特別配方不單可以徹底清潔餐具和銀製器皿，亦可以回復它們本來的光澤。

## Benefit: 優點：

### Immediate brightening

光潔如新

Special ingredients of Bright Silver Detarnisher enable cutlery and silver ware to be cleaned thoroughly and recovered their brightness after use.

Bright 浸銀粉的特別配方可徹底清潔和回復餐具及銀製器皿原來的光澤。

### Safe to use

使用安全

No vigorous chemical reaction will occur on silver and aluminum.

使用在鋁或銀上都不會有激烈的化學反應。



Packing: 5Kg X 4 bottles

Size: 45.0cmX45.0cmX22.0cm

### Easy to use

使用簡單

Only a few simple steps are required to accomplish the task.

整個清潔過程祇有數個簡單的步驟。

# Pro-Kit Bright Silver Detarnisher

**Application: (Direction of use)**

1. Cover the base of a non-metallic container with an aluminum foil and then fill it the container with water at 40-50°C.
2. Add Bright Sliver Detarnisher into the water (10-20g/litre).
3. Place silver ware into the container with no overlapping each other. Then wait for 30 minutes.
4. Rinse with water, clean the silver ware with dishwashing machine with non-bleach detergent.

**應用：（使用方法）**

1. 用錫紙將非金屬容器的底部覆蓋，然後加入40-50°C的水；
2. 將Bright 浸銀粉加入水中（10-20克/公升）；
3. 將銀器沒有重疊地放入容器之中，然後等30分鐘；
4. 用水沖洗，以沒有使用漂白水的洗碗碟機清潔。

<b>Specifications</b>	
<b>Active Ingredients:</b>	
Surfactant	< 5.0%
Sodium carbonate	20.0%-50.0%
Phosphates	10.0%--30.0%
Color:	White
Form:	Alkalescent
Fragrance:	Base odor
PH:	10-13
Density at 20 degrees Celsius:	0.5-1.2
Solubility in Water:	Complete
Chemical Stability:	Stable
<b>Safe Handling:</b>	
Details information about handling and disposing this product can be found at a separate Material Safety Data Sheet. Please make sure the employees/users can fully understand the content of Material Safety Data Sheet and read through it before using this product	
<b>Storage Information</b>	
Store this product in the original container at room temperature	